

## Printer Kit Settings

In order to successfully connect a TEC 3000 unit to a printer using the printer kit, settings on both the controller and the printer need to be defined. The controller needs to be in Printer mode and the baud rate set to 9600. The printer should be set on the following

Print Direction .....	Bi-D
Software .....	ESC/P
High speed draft.....	On
I/F mode.....	Serial
Auto I/F wait time .....	10 seconds
Baud rate .....	9600BPS
Parity .....	None
Data Length .....	8bit
Parallel I/F bidirectional mone .....	On
Packet Mode .....	Auto
Character Table .....	PC 437
International character set for Italic table .....	Italic U.S.A.
Auto CR (IBM 2380 Plus).....	Off
IBM character table .....	Table1

The default settings can be changed from the printer's control panel. Make sure paper is loaded into the printer and turn the unit off. Wait 5 seconds, while depressing the Tear Off button, turn on the printer. Pressing the Tear Off button again prints the instructions to change the default settings.

## **Cabosil Inserts for a Cryoshipper Mini**

---

Below is some information for the cabosil inserts designed to be used in conjunction with the Cryoshipper Mini. The inserts can be mixed and matched to the customers specifications.

Insert Size	Amt of Cabosil (lbs)	Part Number	Hold Time (days)
2"	0.75	11046952	2
3"	1.00	11046944	2.8
4"	1.5	11046936	4

Note: The hold time was determined using 2 inserts



[www.PrincetonCryo.com](http://www.PrincetonCryo.com) | [Sales@PrincetonCryo.com](mailto:Sales@PrincetonCryo.com) | 800.232.2796